

Replacing your Stove Door Rope Seal

Please fully read these instructions before continuing. Do not install while the stove is hot or in use.

Observe safe working practices (please refer to the stoves Installation Guide) whilst replacing the door seal.

Parts Included



Rope Adhesive



Tape



Rope Seal

Step 1

Open the door and lift it off its hinges. Lay the door face down onto a soft surface.



Step 2

Take note of the layout of the old rope, then remove it from the door.

Use a wire brush or similar to remove the old adhesive or flaky paint. This is to ensure optimal adhesion for the glue.

Step 3

Lay the length of rope along the channel in the door where it will sit (ensuring that it is not stretched) and mark where you will need to cut the rope so that the ends will meet/overlap.

Step 4

Cut a strip of the included adhesive tape approximately 65mm long and remove the protective backing. Wrap this tightly around the rope where it will be cut. This is to prevent the ends from fraying.

Cut through both the tape and rope.



Step 5

Follow the instructions on the adhesive bottle on how to apply it.



Allow 30 minutes for the adhesive to cure before

re-fitting the stove door back onto the stove body.



You should periodically check the fire door rope seal for signs of wear and tear.